



Start Here

Start here.

Starten Sie hier.

Commencez ici. Destinazione.

Empezar aquí. Comece aquí. Begin hier.

Rozpocznij tutaj. Начните отсюда. Buradan Başlayın.

Ξεκινήστε εδώ. ابدأ هنا. Start her. Aloita tästä. 'Börja här'.

Begynn her. Začnite tu. Začňte zde. Kezdés itt. ここで開始.

从这里开始。從這裡開始。여기에서 시작.




For Windows®

1



2



WD
EasySetup.exe

3



Router Login User Name: **admin** Password: **password**



For Mac® / Tablet / Browser



1



(no password)

2



<http://192.168.1.1/>
(or <http://wdrouter>)

3



Router Login User Name: [admin](#) Password: [password](#)

Technical Support Services

<http://support.wdc.com>
www.westerndigital.com



If you encounter problems with this product, please contact WD Technical Support.

United States / North America (English and Spanish) 855.842.5370

Asia Pacific +800.855.84253
Japan 00 855 84253

Europe (toll free*) 00 800.855.84253

* Austria, Belgium, Denmark, France, Germany, Ireland, Italy, Netherlands, Norway, Spain, Sweden, Switzerland, United Kingdom

Africa 00 800.855.84253

Western Digital, WD, and the WD logo are registered trademarks of Western Digital Technologies, Inc. in the U.S. and other countries. Other marks may be mentioned herein that belong to other companies. Specifications subject to change without notice.

© 2012 Western Digital Technologies, Inc. All rights reserved.

Western Digital
3355 Michelson Drive, Suite 100
Irvine, California, U.S.A. 92612

